



## Technical Bulletin

June 1, 2020

### Guidelines for Installing Dexerdry with Fiberon Decking

John Ardolina VP R&D

[jardolina@gmail.com](mailto:jardolina@gmail.com)

848-333-3782

**Reason/Purpose** - To ensure a successful installation of Dexerdry with any deck board, and to preserve the applicable warranties, Dexerdry requires the installation be completed with adequate ventilation throughout the deck area and under the decking surface. This is accomplished as per this Technical Bulletin.

### **Technical Details** -

Any installation of Dexerdry is done per Dexerdry's written instructions which are available on-line on the web site - [www.dexerdry.com](http://www.dexerdry.com)

The underside of the decking is left open for ventilation.

If a ceiling is added, there must be a minimum of 1 ½" of continuous ventilated screen along the border (fascia) to create ventilation between the underside of the joists and the ceiling, or a fully ventilated soffit/porch ceiling board is required.

Please note that Dexerdry is not recommended for interior living area or space, it is an exterior product and all local building codes must be followed.

The installation would also have to conform to all other aspects of the deck board manufacturer's written instructions.